

# JL32 series coffee machine

## Instruction Manual



Read the manual carefully before use and keep it safe

**JETINNO®**

Guangzhou Jetinno Intelligent Equipment Co., LTD

[www.jetinno.com](http://www.jetinno.com)

(86) 020-32038721

(86) 400-017-9997

Address: 4/F, Building a, Dehao Innovation Park, No.2 Ruitai Road, Huangpu District, Guangzhou City, Guangdong Province

Postal code: 510700

## Contents

1 Introduction .....	4
1.1 Welcome to use .....	4
1.2 Logos and symbol.....	4
2 General Safety Tips .....	5
2.1 Danger to users .....	5
2.2 Hazard to the machine.....	8
3 Product Description.....	9
3.1 Welcome to use .....	9
3.2 Technical Data .....	10
4 Installation and commissioning .....	10
4.1 Set Up .....	11
4.1.1 Locations .....	11
4.1.2 Climatic conditions .....	11
4.2 Power supply.....	12
4.2.1 Conditions.....	12
4.2.2 Power connection cable .....	12
4.3 Water interface/drain.....	13
4.3.1 Conditions.....	13
4.3.2 Water intake conditions .....	13
4.4 Installation.....	13
4.4.1 Unwrap the machine.....	13
4.5 Disassembly and disposal of scrap.....	14
5 Operations .....	14
5.1 Equipment introduction .....	15
5.1.1 Machine external operating unit .....	15
5.1.2 Product configuration parameters.....	16
5.1.3 Accessories .....	17
5.2 Unwrap.....	19
5.3 Check before turning on .....	19
5.4 Add and connect .....	19
5.4.1 Connecting water source.....	19
5.4.2 Connecting the external wastewater pipe .....	20

5.4.3 Refrigerator connection .....	20
5.4.4 Refrigerator power supply connection .....	20
5.5 Turning on.....	21
5.5.1 Coffee Machine .....	21
5.6 Network connection .....	22
5.7 Server connection .....	23
5.8 Setting Date/Time .....	24
5.8.1 Counters .....	25
5.8.2 Diagnostic.....	26
5.8.3 Machine Reset .....	28
6 First use .....	29
6.1 Filling canister.....	29
6.2 Adding milk to the milk box in the refrigerator .....	30
6.3 Debugging and calibration.....	31
6.3.1 Method for adjusting the thickness of coffee bean grinding powder.....	31
6.3.2 Warm milk and foam temperature regulation.....	31
6.3.3 Grinder calibration.....	32
6.3.4 Fresh milk calibration .....	33
6.3.5 Powder calibration.....	34
6.4 Product Testing and Adjustment.....	35
6.4.1 New Recipe .....	35
6.4.2 .New drink.....	36
6.5 Drink management.....	37
6.6 Drink production.....	38
6.7 Operator Options.....	39
6.8 Empty .....	41
6.8.1 Coffee grounds bin .....	41
6.8.2 Water tray.....	42
6.9 Transportation conditions.....	42
6.10 Turning off.....	42
6.10.1 Operation end .....	42
6.10.2 Long downtime (over 1 week).....	43
7 Cleaning.....	44

7.1 Cleaning interval.....	44
7.2 Cleaning plan.....	45
7.3 Daily rinsing .....	45
7.3.1 Brewer rinsing .....	45
7.3.2 Milk system rinsing.....	46
7.3.3 Mixer rinsing .....	46
7.3.4 Automatic rinsing settings .....	47
7.3.5 Cleaning of water tray .....	48
7.3.6 Cleaning of waste bin .....	49
7.3.7 Clean and disassemble the foamer .....	49
7.4 Regular cleaning .....	50
7.4.1 Cleaning agents .....	50
7.4.2 Display screen guided cleaning program .....	51
7.4.3 System cleaning.....	52
7.4.4 Milk system cleaning.....	53
7.4.5 Brewer Cleaning.....	55
7.4.6 Deep cleaning mixer .....	56
7.4.7 Cleaning touch screen .....	56
7.5 Clean the coffee bean container weekly.....	57
7.6 Empty waterway.....	57
7.7 Descaling .....	58
8 List of Common Problems .....	63
9 Preventive measure .....	64
9.1 Cleanser.....	64
9.1.1 Use.....	64
9.1.2 Storage .....	65
9.1.3 Disposal of waste .....	65
9.2 Health Regulations.....	65
9.2.1 Water .....	65
9.2.2 Coffee .....	65
9.2.3 Finished drink powder.....	66
10 Safety and Quality Assurance .....	66

## 1 Introduction

### 1.1 Welcome to use

This instruction manual gives you the information of JL32 and other products and how to use them. If you do not use the coffee machine according to the relevant instructions in this manual, we do not assume any responsibility for the loss caused by this. However, all intended uses may not be included in the instruction manual! For more information, please contact our customer service.

Equipment performance depends on proper maintenance and use. Please read the instruction manual carefully before the first commissioning and keep the instruction manual for easy access.

This manual is applicable to: JL32A、JL32B、JL32C.

Wish you a happy use!

### 1.2 Logos and symbol



See also the "General Safety Tips" section.

The following signs and symbols are used in the instruction manual to indicate hazards and special matters:



#### **Danger**



- Immediate danger situations, which may result in serious injury or death due to electric shock.
- Be sure to follow precautions to prevent such hazards.



#### **WARNING**



- A general hazardous situation that can cause serious injury.
- Be sure to follow precautions to prevent such hazards.



#### **CAUTION**

- General hazardous conditions that can cause minor injuries.
- Be sure to follow precautions to prevent such hazards.



#### **NOTE**

- Conditions exist that could cause damage to the machine.
- Be sure to follow the precautions to prevent such hazards.



#### **WARNING**

- Fire hazard/combustible materials.
- Watch out for fire.



#### **CAUTION**

- Hot liquids. A dangerous condition that may cause burns. A hazard exists at the flow outlet location.
- Only symbols are used for identification below.
- Be sure to follow the precautions to prevent such hazards.



## ⚠ CAUTION

- Hot steam. Dangerous condition that may cause burns. The location of the water outlet creates this hazard. Only symbols are used in the following.
- Be sure to follow the precautions to prevent such hazards



## ⚠ CAUTION



- Hot surfaces. Dangerous conditions that can cause burns. Stream exit location.
- Location (optional) to create this hazard. Only symbols are used in the following.
- Be sure to follow the precautions to prevent such hazards.



## ⚠ CAUTION

- Crush hazard. Dangerous conditions that can cause splint injuries.
- Only symbols are used for identification below.
- Be sure to follow the precautions to prevent such hazards



## ⚠ WARNING



- Poisoning hazard. A general hazardous condition that may result in injury from poisoning. In the following
- Identification by symbol only.
- Be sure to follow precautions to prevent such hazards.

## 2 General Safety Tips

### 2.1 Danger to users



## ⚠ CAUTION

Improper use of a coffee machine can result in minor injuries.

Be sure to follow the following:

Read the instructions carefully before use.

- Only allow technical service personnel to enter the maintenance area of the machine.
- Do not use the coffee machine if it is not working properly or is damaged.
- Do not change the built-in safety device.
- Do not touch hot machine parts.
- Children over 8 years of age and persons with physical, sensory, or intellectual impairments or who lack experience and cognition should only use equipment under constant supervision after learning how to operate it safely and understanding the risks associated with it.
- Do not allow children to tamper with machinery. Cleaning and user maintenance tasks must not be performed by children. Only persons familiar with and experienced with the equipment are allowed to

perform such work, especially as it relates to safety and hygiene.

- Install the coffee machine in a place where it can be looked after and maintained at all times.
- Self-use and operation should be supervised by trained personnel to ensure compliance with maintenance regulations and to resolve usage issues at all times.<sup>7</sup>
- Only coffee beans should be filled in the coffee bean tank, and only ground coffee beans should be added to the manual addition port (or cleaning tablets should be added during cleaning).

---



## **Danger**



Electric shock hazard. Incorrect use of electrical equipment can result in an electric shock.

Be sure to observe the following:

- Work on electrical equipment should only be performed by electrical professionals.
- This machine must be connected to a circuit with a fuse protection (it is recommended to lay the wiring through a leakage protector).
- Please comply with the relevant low voltage directives and national or local safety regulations.
- Connections must be grounded in accordance with regulations to prevent electric shock.
- The voltage must be consistent with the instructions on the device nameplate.
- Do not touch live parts.
- Be sure to turn off the main switch and disconnect the device from the power supply before performing maintenance.
- All connectors of the device must be able to disconnect from the power grid.
- Disconnected connections must be visible at all times at the point of operation of the equipment, or power must be secured by locking.
- Only professional technical support personnel can replace the power cable.

---



## **WARNING**

If the safety tips are not followed, there may be negligence in normal use, which will cause harm to personnel and the surrounding environment!

- Ventilation should be maintained around the machine or in the embedded structure without obstructions.
- There should be no inflammables around the machine.
- Do not use mechanical devices or other means to accelerate defrosting other than those recommended by the manufacturer.
- Do not damage the refrigeration circuit.

---



## **CAUTION**

Drinks with additives or residues may cause allergies.

Be sure to follow the following:

- In the self-service application, express the possible use of allergenic additives through the coffee machine prompt board.
- In the case of a service person application, a trained person should inform you of possible allergenic additives

---



## **⚠️ WARNING**

Danger of poisoning from ingestion of cleaning agents.

Be sure to observe the following:

- Cleaning agent storage should be kept away from children and unauthorized persons.
- Do not ingest cleaning agents.
- Do not mix cleaning agents with other chemicals or acidic substances.
- Do not add cleaning agent to the cup.
- Do not add cleaning agent to drinking tank (inside/outside).
- Cleaning agents and descaling agents should only be used for their stated purpose (see label).
- Do not eat or drink while using the cleaning agent.
- Good ventilation and venting must be ensured when using the cleaning agent.
- Protective gloves should be worn when using the cleaning agent.
- Safety goggles should be worn when using detergent.
- Wash your hands thoroughly immediately after applying the detergent.



Read the package instructions carefully before using the cleaner. If a safety data sheet is not provided, you can ask the distributor for it (see Packaging of the cleaner).



## **⚠️ CAUTION**

- High temperature liquid. Risk of burns in the exit area of drinks, hot water and steam.
- During export or cleaning do not extend your hand below the flow outlet position.



## **⚠️ CAUTION**

Hot surface. High temperature exists in the flow outlet position, ES brewer and boiler.

- Only allow contact with handles pre-designed for output.
- Clean the ES brewer only after the coffee machine has cooled



## **⚠️ CAUTION**

Squeeze \ scratch hazard. There is a risk of being crushed by touching any moving part.

- Only handles pre-designed for output are allowed to be touched.
- Do not reach into the opening of the coffee bean trough, powder trough, or brewer after starting the coffee machine.
- The blades on the grinder disk and the coffee trough opener blades are sharp and should be taken care of during cleaning.

## 2.2 Hazard to the machine



### NOTE

Improper use of the coffee machine can cause damage or contamination.

- Be sure to follow the following:
- If the carbonate contained in the water is harder than 5°DKH, install a scale filter, otherwise it will damage the coffee due to calcification.
- For safety reasons, please note that the main water valve (coffee machine with tap water interface) should be turned off after shutdown, and the main switch should be turned off or the plug should be unplugged.
- Please comply with the relevant low voltage directives and/or national and local safety rules and regulations.
- If water injection is not possible, do not turn on the device. Otherwise you will not be able to refill the water boil and the pump will run "dry"
- It is recommended to install a ball valve in the water pipe when connecting to the direct drinking water to avoid water seepage hazards when the hose breaks.
- After a long shutdown (such as a corporate holiday), the coffee machine must first be cleaned and then turned back on for use.
- Protect the coffee machine from weather - empty the tank (frost, moisture, etc.).
- Troubleshooting should only be done by a technical service person.
- Use original parts for repairs.
- For visible external damage or leakage, contact your service partner immediately for replacement or repair.
- Do not rinse the machine with water or clean it with steam cleaner.
- Do not place the machine where it may be sprayed with water.
-  Protect the ground.
- If you do not use the machine for a long time, it is recommended to use up all the coffee beans in the bean bin, otherwise the residual coffee beans will absorb moisture in the air, and it is easy to cause the grinder to block when grinding again;
- If the boiler is not regularly descaled, it will have the following effects: the heating speed slows down and the temperature is not enough; abnormal coffee taste, resulting in boiler damage.



### NOTE

Proper use of the coffee machine can cause damage or contamination.

Be sure to follow the following points:

- Only coffee beans can be filled in the coffee bean tank, only finished drink powder can be filled in the powder tank, and only ground coffee beans can be added to the manual addition port (or cleaning tablets can be added when cleaning).
- Do not use freeze-dried coffee, otherwise it will cause the ES brewer to stick.

- If the coffee machine and its additional equipment are transported at a temperature below 10 °C, the coffee machine and its additional equipment must be placed at room temperature for three hours after transportation, and then connected to the power supply and started. Failure to comply with this regulation may result in a short circuit hazard or damage to electrical components due to condensation.
- Use a hose kit (drinking water/wastewater hose) that is new or comes with the machine.
- An old hose kit must not be used

---



## NOTE

- Improper use of the coffee machine can result in injury;
- Climbing on top of the machine is strictly prohibited.

---

## 3 Product Description

### 3.1 Welcome to use

The JL32 is used to make and output various types of coffee drinks and milk drinks with syrup.

The equipment is suitable for commercial use in hospitality, catering or similar establishments. The equipment is self-serving and unattended, and can be operated by non-professionals or by guests themselves. User maintenance should only be carried out by trained outside operators.

If installation conditions can always be met, the device can also be used in a train station, gas station shop, or similar public place. The machine is not designed for outdoor installation or use.

Children over 8 years of age and persons with physical, sensory or intellectual impairments or who lack experience and cognition should only use the equipment under constant supervision after learning how to operate it safely and understanding the risks associated with it. Do not allow children to tamper with machinery. Cleaning and user maintenance tasks must not be performed by children.

Only persons familiar with and experienced with the equipment are allowed to perform such work, especially as it relates to safety and hygiene.



Addition, refer to the terms and conditions of the manufacturer of the equipment and this instruction manual when using the coffee machine. Any other use or use beyond the limits is considered unreasonable use. The manufacturer shall not be liable for any loss arising therefrom



## NOTE

- Hazard to machinery.
- Incorrect operation of the coffee machine may cause damage to the equipment, use the original recipe, do not use other recipes.

---

### 3.2 Technical Data

Name	Parameters
Model	JL32 series
weight	30kg
Rated voltage/frequency	AC220-240V/50-60Hz
Rated power Total power	2700W
Fused current	16A
Coffee machine operating temperature/humidity	5°C-40°C/10%RH-90%RH
communication interface	USB;WIFI;4G
Device display screen	10.1-inch display touch screen
Support cup height	Less than 165mm
Coffee bean storage capacity	1500g
Powder canister capacity	2pcs, Capacity: 2L + 3L (milk powder 1kg、chocolate powder1.2kg)
Drip tray capacity	0.6L
Waste bin capacity	40pcs cakes (8g/pcs)
Water tank capacity	4L
Hot water boiler capacity/power	700CC\2700W
Steam boiler power	1400W
Coffee bean no bean detection function	YES

### 4 Installation and commissioning

 Machines should be installed in accordance with the electrical and hygiene regulations in force in each country or locality. These include taking adequate backflow protection measures.



- Sharp edges of packaging materials can lead to injury. Cutting nylon cable ties may make
- Eye injury. Wear gloves when unpacking the machine and keep safety goggles on.



## CAUTION

- Contaminated water inlet pipes may pose a health hazard. It must be cleaned after installation, commissioning or commissioning again.
- Before the initial output of drinks, clean according to the cleaning program guided by the display screen.
- See "Cleaning" - "Daily Machine Cleaning" - "Screen Guided Cleaning Program"

### 4.1 Set Up

#### 4.1.1 Locations



## NOTE

Hazard to machinery.

The following conditions are suitable for placing a coffee machine.

Failure to guarantee these conditions may damage the machine.

- Do not put the machine upside down, horizontally or vibrate the machine when handling, and do not move the machine at an Angle greater than 45°.
- Before the machine is installed, ensure that the refrigerator with fresh milk has been placed forward for at least 24 hours.
- The mounting surface must be stable and flat, and will not deform under the weight of the coffee machine.
- The distance between the necessary energy interface set according to the site installation drawings and the machine position must not exceed 1 m.

#### 4.1.2 Climatic conditions



## NOTE

Hazards to machinery.

The following climatic conditions are suitable for placing coffee machines. If these conditions are not guaranteed, the machine may be damaged.

Be sure to observe the following conditions:

- The ambient temperature should be maintained at 5 ° C - 40 ° C.
- The maximum relative air humidity is 10%RH-90%RH.
- Coffee makers are designed for indoor use only. It must not be used outdoors to protect it from the weather (rain, snow and frost)!



## NOTE

Low-Temperature Storage Requirements:

- If a coffee machine that has been in normal use needs to be stored or transported in an environment where the temperature is below 0°C, it is essential to first perform a water drainage procedure to empty the water system.

## 4.2 Power supply

### 4.2.1 Conditions

Electrical connections must be made according to the relevant regulations of the host country. The voltage at the installation site must be consistent with the voltage given on the nameplate.



#### **Danger**

Electric shock hazard! An immediate danger situation that can result in serious injury or death due to electrocution.

Be sure to observe the following:

- All power supply circuits must be turned off before touching the terminal!
- Leakage protection devices must be protected by fuses with amperage values indicated on the nameplate!
- All connectors of the device must be able to disconnect from the power grid.
- The JL32 series models can only be connected to a power supply with a system impedance of 0.293 ohms or less. Consult the authority of your system impedance information provider if necessary.
- Do not run the machine when the power cord is damaged. Replace the damaged power cord or plug immediately by a professional technical service person.
- It is recommended not to use an extension cable! If you must use an extension cable (minimum cross section: 1.5 mm<sup>2</sup>), follow the manufacturer's data (instruction manual) for the cord and local regulations.
- When laying out the power cables, make sure that the power cables will not trip people.
- Do not drag the cable at sharp or sharp corners, and do not clip the cable or leave it hanging in the air. In addition, cables should not be placed over hot objects and should be oil and corrosive cleaners resistant.<sup>15</sup>
- Do not lift or pull the device through the power cord. Do not pull the plug out of the socket by pulling on the power cord. Never touch the power cord or plug with wet hands! Do not plug wet plugs into sockets!

### 4.2.2 Power connection cable



#### **NOTE**

Danger to the user.

There is a risk of electric shock and fire if the power connection cable is damaged or non-original!

Use an original power connection cable.

- Be sure to follow precautions against such hazards:

Country-specific original power connection cables can be purchased through service partners.

Power connection cables with fixed connections should be replaced by technical service personnel.

## Connection value

1. Refer to the nameplate on the machine.

2. Optional device

Refrigerator: When using a coffee machine to make coffee drinks,

The refrigerator is specifically used to refrigerate milk.

Pre cooled milk (2-5 °C) can be used.

Only specialized milk system cleaners can be used.



## 4.3 Water interface/drain

### 4.3.1 Conditions



#### NOTE

Poor quality raw materials and poor water quality can damage the machine.

Be sure to follow the precautions against such hazards.

Be sure to observe the following:

- The water used must be clean and pollution-free, with no more than 50 mg of chlorine per litre of water.
- Do not add reverse osmosis water or other corrosive water to the coffee maker.
- Carbonate hardness should not exceed 5-6°DKH (German carbonate hardness) or 8.9- 10.7°FKH (French carbonate hardness).
- The minimum carbonate hardness is 5 °DKH or 8.9 °FKH. The PH is between 6.5-7.
- Use the new hose kit (clean water/waste water hose) that comes with the machine.
- The water source must be connected in accordance with current regulations as well as the regulations of the country in which it is located. If the machine is connected to a newly installed water pipe, the water pipe and water inlet hose must be thoroughly rinsed to prevent stains from entering the machine.
- The machine is connected directly to an external drinking water tank or waste water tank.
- Corresponding level monitoring is available.

### 4.3.2 Water intake conditions

Water Pressure	0.05 MPa - 0.6 MPa (0.5 - 6 bar) recommended	
Inlet temperature	Minimum	5°C
	Maximum value	30°C

## 4.4 Installation

### 4.4.1 Unwrap the machine

Read the "Set Up" and "Power Supply" sections carefully before starting the installation!



Pay attention to the installation instructions that come with it!

- Unwrap the machine.
- Check the package to see if any accessories are left in it.
- Remove the accessories provided with the package.



Auto Debugger Run debugger automatically the first time you turn it on. All installation items will be explained in it. Technical service personnel can start the debugging program at any time.

#### 4.5 Disassembly and disposal of scrap

Proper disposal of coffee machines must be done in accordance with local regulations.

- Contact a service partner agency.



### 5 Operations



#### CAUTION

- Hot liquid. Drinks made with this machine are hot drinks.
- Do not put your hand under the outlet of the drink or into the machine during discharge.



#### CAUTION

- High temperature steam. Risk of burns in the steam nozzle exit area.
- Do not put your hand under the steam nozzle during output.



#### CAUTION

- High temperature surface. Dangerous conditions that can cause burns. Drink outlets and water brewers present this hazard.
- Do not grip the outlet of the drink or touch the surface of the boiling device while it is heating.




#### NOTE

- Hazard to the machine. Wrong operation may damage the touch screen.
- Do not press the display with brute force, high pressure, or sharp objects.


## 5.1 Equipment introduction

### 5.1.1 Machine external operating unit

- [A] coffee bean container
- [B] 10.1-inch touch screen (operation interface)
- [C] product spout
- [D] cup holder
- [E] water tray
- [F] powder canister
- [G] Hot water spout
- [H] Built-in water tank



- [ J ] Dehumidifying fan
- [ K ] External interface for water tray  
(please open the rubber plug for tray)
- [ L ] MDB socket
- [ M ] Power switch
- [ N ] Cooling fan
- [ O ] External water source inlet
- [ P ] Power cord socket



### Product interface



### 5.1.2 Product configuration parameters

Product configuration parameters			
Product name	JL32A	JL32B	JL32C
Model+Config	JL32-ES3C-FV	JL32-ES1C-FV	JL32-ES3C
Recommended daily cups (cup/day)	200	200	200
External dimensions (width * height * depth)	350*620*560mm	350*620*560mm	350*620*560mm
Net weight of equipment	30kg	29kg	29kg
Voltage/Frequency	220-240V 50/60Hz	220-240V 50/60Hz	220-240V 50/60Hz
Rated power	2900W	2900W	2700W
Operation interface	10.1 "Touch screen (Horizontal)	10.1 "Touch screen (Horizontal)	10.1 "Touch screen (Horizontal)
Coffee bean container	1x 1500g	1x 1500g	1x 1500g
Grinder	1x Jetinno PGH64	1x Jetinno PGH64	1x Jetinno PGH64
Italian high-pressure brewer	P20(Double layer filter)	P20(Double layer filter)	P20(Double layer filter)
Instant canister	1x 3L + 1x 2L	/	1x 3L + 1x 2L
Mixer	1 pcs	/	1 pcs
Hot water boiler	700ml, 2700W	700ml, 2700W	700ml, 2700W
Steam boiler	Thermal block, 1400W	Thermal block, 1400W	/
Pump model	2x piston pump	2x piston pump	1x piston pump
Drink spout height	165mm(With low cup holder)	165mm(With low cup holder)	165mm(With low cup holder)
Independent hot water pipe	Yes	Yes	Yes
Fresh milk foam module	Yes(Simultaneously producing fresh coffee and milk)	Yes(Simultaneously producing fresh coffee and milk)	/
Fresh milk freezer	Optional,4L	Optional,4L	/
Waste bin capacity	40 pcs cakes (8g) , Optional waste discharge	40 pcs cakes (8g) , Optional waste discharge	40 pcs cakes (8g) , Optional waste discharge
Water tray capacity	0.6L, Optional waste discharge	0.6L, Optional waste discharge	0.6L, Optional waste discharge
Water supply method	Standard configuration: 4L built-in water tank;	Standard configuration: 4L built-in water tank;	Standard configuration: 4L built-

	Optional: Direct drinking water;	Optional: Direct drinking water;	in water tank; Optional: Direct drinking water;
Networking methods	Deerror WiFi, optional 4G	Deerror WiFi, optional 4G	Deerror WiFi, optional 4G
Payment system	Payment function: WeChat, Alipay; Optional external MDB devices	Payment function: WeChat, Alipay; Optional external MDB devices	Payment function: WeChat, Alipay; Optional external MDB devices
OS	Android	Android	Android
IOT	Optional, SaaS Internet of Things Cloud based remote management system	Optional, SaaS Internet of Things Cloud based remote management system	Optional, SaaS Internet of Things Cloud based remote management system
Authentication	CE,CB,CQC	CE,CB,CQC	CE,CB,CQC

### 5.1.3 Accessories

#### Subsidiary accessories

Fully automatic coffee makers come with the following accessories when supplied:

Graphical representation	Item name	Functional specifications	Product parameters
	User manual	For coffee machine use reference	210mmx291mm
	Coffee maker, pack of consumable materials (seals, strainers, etc.)	For daily consumable replacement of coffee machine	Regular
	Small inner hole cleaning brush	Use when cleaning milk tube, milk foam, inner hole	Gross diameter 3mm* Total length 21cm Gross diameter 6mm* total length 21cm
	Tank foam maglev and tank seal ring	For in tank	/
	Milk tube cover	For the left milk tube of the machine	/
	Drip tray foot	Used for fixing the bottom of the water tray	/
	Fuse wire	Spare parts for machine power supply	6mm*30mm
	External water connection	Connect the drinking water connector	/

	Install sheet metal in the waste slag bucket	For anti-theft slag bucket (after installation, open the door to remove the slag bucket)	/
	Power cord	For coffee machine special function installation use	Three plug (16A)
	Installation accessories for coffee machine (drain pipe outside the water tray)	Used for the installation and use of special functions in coffee machines	Inside diameter 20, outside diameter 23
	Outer drain pipe shell	Install it on the drainpipe to prevent the water pipe from warping and the water tray from remaining	bend

#### Optional accessories

Graphical representation	Item name	Functional specifications	Product parameters
	Milk cold bin	For refrigeration and fresh use	260 (W) x600(H)x426(D)mm, capacity 9L
	Fresh Granny box	Container for holding fresh milk	Food grade, 5L
	Payment side cabinet (customizable)	External payment device side cabinet	Customize specific currencies according to the MDB protocol
	Bottom cabinet (customizable)	Bottom cabinet for placing coffee machine	Customizable
	Coffee system cleaning pills	Used to clean coffee machine ES brewer	2 g/tablet, 100 tablets/can, 12 cans/box
	Coffee maker milk system clean tablets	For cleaning the milk system	4g/ tablet, 120 tablets/bottle, 12 bottles/case

## 5.2 Unwrap



After receiving the machine, unpack, remove the foam, uncover the PE bag, and lift the machine to the flat table top.

## 5.3 Check before turning on

Check that the following prerequisites are met before turning on the coffee machine.

- The main water valve has been opened or the tank has been filled with water.
- The waste water outlet is properly set/the water tray is properly placed.
- Bean containers are filled.
- Coffee grounds box emptied and properly inserted.
- The power cord is connected to the power supply.

## 5.4 Add and connect

**i** Special care must be taken when replenishing that the maximum amount of filling must not cause the container lid to come into contact with the contents.

### 5.4.1 Connecting water source



#### NOTE

Water quality affects human health! Water sources must meet the sanitary standards for drinking water

- Pay attention to the sanitary condition of water pipes.
- Wash the relevant parts.
- The water source to which the machine is connected should be easy to operate.
- Tighten the joint for direct drinking water to avoid water leakage.

#### A. Internal water source (water tank)



Pull out the water tank, remove the tank cover, fill the tank with clean water, and install the tank back into the machine. The water tank has a water level detection, and there is a prompt on the water shortage interface.

## B、External water source (direct drinking water)



Unscrew the cover on the water inlet valve, take out the interface from the machine, install the interface to the water inlet connection, turn it clockwise, and insert the tube into the interface.

Note: The water connected to the system is the internal water source by default.

The external water source has two ways: direct drinking water and barreled water. Choose one of these two ways. The customer can connect the water source according to the demand of the order. If you need to connect another water source, you need to open the back cover of the machine, adjust the pressure reducing valve according to the guidance on the back cover, and then connect the other water source.

Direct drinking water interface:



- A pump running without water can damage the machine.
- Make sure the main water valve is open before turning it on.



When stopping, make sure the main water valve is closed.

### 5.4.2 Connecting the external wastewater pipe



As shown in the figure above, pull out the water tray, remove the grid, and take out the plug of the water tray; the waste water pipe is inserted into the interface at the back of the machine, after that, install the bent connector on external waste water tube.

Directly using a water tray can ignore this step.

### 5.4.3 Refrigerator connection

Insert one end of the coffee machine milk tube into the interface on the right side of the refrigerator, straighten the milk tube, and move the refrigerator to be level with the coffee machine cabinet.


### 5.4.4 Refrigerator power supply connection

Insert the female connector of the refrigerator power cord into the socket of the machine; Insert the other end of the power cord into the socket of the power supply; Press the refrigerator power switch.


## 5.5 Turning on

### 5.5.1 Coffee Machine


- Check the power connection of the machine.




Machine startup, turn on the power switch; Select the corresponding machine configuration based on the nameplate on the back of the machine




Choose wastewater drainage method



Choose water supply method



Water filter selection





Display the main interface and start heating





The boiler heats and boils water, and when the water temperature reaches the set temperature, the machine is ready.



## 5.6 Network connection




Press upper left corner of the screen for a while, enter the password test9527 in the pop-up dialog box, enter the machine background, and click "Machine Set-up".




Select the "Maintenance" button and click "Exit APP" in the pop-up interface. The prompt is "Are you sure you want to exit the APP?" Click "Yes".



On the Android interface, click the "Settings" button and click "WIFI" in the pop-up window.




Turn on the switch, the machine will automatically search for WIFI, click on the name of the WIFI that needs to be connected, enter the password in the pop-up dialog box, and click "Connect".




Click on the circle on the screen to enter the Android main interface, click on the "Coffee" icon to enter the coffee machine app.

Note: Under Offline model, there is no need to connect to the network and this step can be ignored.


## 5.7 Server connection



Press the upper left corner of the screen for a while, and click "OK". Enter the backend management interface and click "Diagnostic".



Click on "Software and Operation Version" ->"Telemetry" to turn on/off the online mode and open it. Click the return button in the upper right corner of the screen to return to the upper interface.




Click on "Diagnostic Tests" ->"Status Inquiry" to view: Service Connection Installation Status; Service Connection Status (green circle), indicates successful connection to the server; Service Connection Status (grey circle), indicates a failure to connect to the server; If the connection to the server fails, please contact the local operator or agent to confirm whether the machine has been registered on the server.


Note: Under offline model, there is no need to connect to the server and this step can be ignored.

## 5.8 Setting Date/Time

When the user receives a machine connected to the network, the machine system time will be automatically updated and synchronized with the local time; when under offline model, the system time cannot be updated to synchronize with the local time, and the local time needs to be manually set. The specific methods are as follows:




Enter the machine background, click "Clock Setting ->Date & Time" in the pop-up interface, Use network-provided time to open it, and the system time will be automatically updated and synchronized with the local time;




Under offline model, click "Use network-provided time" to turn it off, manually "Set date", "Set time", and "Select time zone". Click on shortcut keys   back to the main interface of Android, click on the "Coffee" icon, and re-enter the app.

### 5.8.1 Counters




Press the upper left corner of the screen for a while, enter the password in the pop-up dialog box, and click "OK". Enter the machine background and click on "Counters".




The pop-up dialog box includes functions such as Product, Products by type, Reset Counters, and Lifetime Counters. Click on "Product", there are counting methods for "Item" and "Total".




Products by type



Reset Counters interface





Lifetime Counters interface by products.





## 5.8.2 Diagnostic

Press the upper left corner of the screen for a while, enter the password (tester: test9527) in the pop-up dialog box, and click "OK". Enter the backend management interface and click the "Diagnostic" button.



The diagnostic functions include software and operational versions, Errors, and Diagnostic Tests. Software and Operating Version - Hardware: Users can check the machine hardware version here;



Software and Operation Version - Machine Series No.: Users can set the machine number here; Telemetry: Users can turn on/off "online mode on/off"

Users can check and update the firmware version of the I/O board here;


Users can check and update application versions here;

Software and Operation Version - Application: Software and Operation Version - Network Status: Users can check and set up the network here. Users can set their SIM card number here (hardware support required); Users can set up IMEI here (hardware support required);


Last errors list	Date/Time	Error code	Error
Reset last errors list	2023-12-29 13:31:16	5800	Drip tray missing. Please insert.
Total errors list			
Reset total errors list			
Reset machine			

Last errors list	Date/Time	Error code	Error
Reset last errors list	2023-12-29 13:31:16	5800	Drip tray missing. Please insert.
Total errors list	2023-12-29 11:58:05	5800	Drip tray missing. Please insert.
Reset total errors list	2023-12-29 11:58:01	9900	Water tank missing. Please insert.
Reset machine	2023-12-29 11:49:32	5A02	Please replace emptied grounds bin.
	2023-12-29 11:49:28	5800	Drip tray missing. Please insert.

Errors - Current Error List: Users can query the current error; error - Total error List: Users can query all error information.





Diagnostic Tests - Status Inquiry: Users can check the status of all machine components here; Diagnostic Tests - Valves test: Users can test all valves inside the machine here.




Heater test: Users can test all boilers inside the machine here;

Motors test: Users can test all sensors inside the machine here.

### 5.8.3 Machine Reset



Press the upper left corner of the screen for a while, enter the password test9527 in the pop-up dialog box, click "OK", enter the machine background, and click the "Diagnostic" button.



Select the "error" icon and follow the prompts on the machine for handling;

Click the "Reset total errors list" button, and the machine will automatically retest.

## 6 First use

### 6.1 Filling canister

1. Opens the canister lid with key and fill the material.



- 1) Wear a mask and disposable gloves;
- 2) Insert the key into the lock on the lid of the canister and rotate to unlock it;
- 3) After unlocking, remove the lid of the canister and add coffee beans and powder to the corresponding canister;
- 4) After adding coffee beans and powder, cover the lid, turn the key, lock the container, and remove the key.

2. Remove the canister and fill the material



Push the coffee bean container to the bottom, lift up and remove the bean container; Pull outward the lock of the canister (pull out 4mm), and lift upward powder canister;

Open the lid of the canister respectively with the key, and fill the corresponding materials into the canister. Put the canister back into the machine after filling the material.

After removing the canister or removing the canister cleaning, pay attention to the following points during installation:

1. When the coffee bean container is put back in place, remember to pull out the bean container material stop plate, otherwise the coffee beans will not fall into the grinder, showing the lack of coffee beans.

2. After place powder canister back to the machine, please press the rear, so that the gear fully bite, and then press the lock back to prevent not in place caused by loose gear and not fall powder meanwhile the back of canister warped.

3. Rotate the canister nozzle to the bottom and align it with the mixer.

Coffee beans



## ⚠️ WARNING

The rotating grinding disc of the grinder can cause injury to people.

Do not reach into the coffee bean container when the coffee machine is turned on



## ⚠️ NOTE

When covering the canister lid, tilt the back first to insert the buckle into the slot and then press down.

Adding foreign objects may cause blockage of the grinder or damage to the grinding equipment!

Do not put any items other than coffee beans into the coffee bean container.

## 6.2 Adding milk to the milk box in the refrigerator



## ⚠️ NOTE

Contamination of milk ducts may pose a threat to health.

After installation, debugging, or re operation, cleaning must be carried out.

Before the initial output of the drink, rinse according to the cleaning program guided by the display screen.

Insert the refrigerator door key and rotate it clockwise to open the refrigerator door;

Take out the milk box, pour the milk into the milk box, put the milk box into the refrigerator, and close the refrigerator door;

Determine the thermostat to be 3 to 5 degrees and adjust the thermostat Settings accordingly; If necessary, pour the pre-cooled milk into the milk pitcher, the height of the milk pitcher should be lower than the height of the coffee machine mouth, and finally close the refrigerator door. If necessary, pour pre cooled milk into the milk can and finally close the refrigerator door.



The customized machine with the function of milk deficiency detection (for vending service) can't use water to replace fresh milk when there is no fresh milk; Water on the surface of the sensor or the use of cloudy water instead of milk will affect the judgment of the sensor, which will be misjudged as fresh milk; Please wipe down water on its surface if necessary, otherwise, the sensor will work abnormally.

Omit this step without fresh milk machine.

## 6.3 Debugging and calibration

### Grinder calibration



#### NOTE

Before adjusting the grinder, please prepare a (low value) electronic scale!

### Grinder thickness adjustment

First calibration, please empty coffee beans (before adjusting the grinder, empty the remaining powder in the grinder)

#### 6.3.1 Method for adjusting the thickness of coffee bean grinding powder



Adjustment knob for the thickness of coffee bean grinding powder, the clockwise direction is to adjust the thickness, the counterclockwise direction is to adjust the fine; Coffee bean box material stop plate, push inside to close, pull out to open; When it is necessary to remove the coffee bean box, the coffee bean box cutting plate should be pushed to the bottom, and the coffee bean box can be lifted up. Adjust the thickness of the grinding degree according to the label: It is recommended that in the absence of beans, first twist the knob counterclockwise to the position where the disc fits (can not be twisted under normal torque), and then rotate the knob clockwise 6 times, as a benchmark thickness position (the thickness of general espresso), and then fine-tune according to the thickness of the powder in the calibration process (clockwise is to adjust the thickness, counterclockwise is to adjust the fine). When fine-tuning, it is recommended to rotate the adjustment knob while grinding the beans. When it is necessary to empty the residual powder of the grinder, the coffee bean discharger plate is closed, click the "Drink Settings" button, select the "coffee" button and click, click the "Grinder calibration" option in the pop-up dialog box, and click the "Start" button several times until no coffee powder falls out of the grinder outlet. hot milk and milk temperature regulation

#### 6.3.2 Warm milk and foam temperature regulation



Open the door of the machine, pull out the protective button upward, you can see the adjustment knob, rotate clockwise by hand, the temperature of hot milk and milk foam will increase, and the flow rate of milk will slow down; On the contrary, rotating counterclockwise, the temperature of the hot milk and milk foam will be reduced, and the flow rate of milk will be faster. It is recommended to fine-tune, each adjustment amplitude is not too large.

### 6.3.3 Grinder calibration

Calibration is a software designed for the physical properties of instant canister, powders, and the degree of roasting of coffee beans. Prepare the electronic scale and cup before calibration.



### WARNING

Not doing calibration will cause abnormal powder production of the machine!


Before calibration, it is necessary to fill the grinder, milk tube, and canister with a full amount of material. Insufficient outlet may result in inaccurate calibration.




### NOTE

Because each component or powder has different physical properties, it is necessary to recalibrate every time the canister, motor, or coffee beans or powder from different manufacturers are replaced. During calibration, the amount of powder in the canister must be greater than one-third of the volume of the canister.


Grinder calibration steps:



Press the upper left corner of the screen for a while, enter the password in the pop-up dialog box, click OK, enter the machine background, and select the "Product Set-up" button.



Select the "Coffee" button and click on it. In the pop-up dialog box, click on the "Grinder Calibration" option and click the "Start" button to grind the coffee powder once and discard it.




Place an empty cup on the electronic scale and reset it to zero, then place the cup at the powder outlet of the grinder; Click the start button again. Wait for the grinder to finish grinding. Remove the cup containing coffee powder and place it on an electronic scale for weighing. Enter the weight value in the blank field of [Input Powder Grams] and click "Save".


#### 6.3.4 Fresh milk calibration

Different milk sources produce different concentrations, and fresh milk needs to be calibrated. Sufficient milk source needs to be ensured during calibration.



Calibration steps for fresh milk



Press the upper left corner of the screen for a while, enter the password in the pop-up dialog box, click OK, enter the machine background, and select the "Product Set-up" button.



Select the "Milk" button and click to select "Milk Foam Calibration" or "Hot Milk Calibration" in the pop-up dialog box.





Click the "Start" button. After the milk froth or hot milk is finished, remove the measuring cup containing the milk froth or hot milk, read the value of the milk froth or hot milk in the measuring cup with your eyes facing straight, input the read value into the blank space below [Input Milk Foam Volume]/[Input Hot Milk Volume], and click "Save".

### 6.3.5 Powder calibration

Because powders have physical properties, different densities, and different processes, calibration is required. During calibration, the amount of powder in the canister should be greater than one-third of the volume of the canister.


Powder canister calibration steps:



Enter the machine management backend. Click on "Product Set-up" and select "Left or Right canister".




Open the machine door, rotate the mixer fixing ring clockwise, unlock, and pull out the mixer outward; Take an empty cup and place it at the canister outlet.



Click the "Start" button to discard the powder that falls into the cup. Place the cup on the electronic scale to reset or peel it, and then place the cup at the canister outlet. Click the "Start" button. After the powder box is finished, remove the cup containing the powder and place it on the electronic scale for weighing. Enter the weight value into the "Input powder grams" field and click "Save".

#### 6.4 Product Testing and Adjustment


Click on [ Recipe Configuration ], and in the pop-up interface, there is a deerror factory recipe for the machine; Selecting the corresponding drink will pop up the corresponding recipe, and clicking [Test] can directly test the drink; The recipe interface has functions such as [Import Recipe], [Export Recipe], [Add Recipe], [Delete Recipe], [Edit], [Test], and [Delete]. Enter the recipe interface, select the product, click [Edit], and adjust the water volume, coffee bean powder, hot milk and foam discharge time of the product (the amount of milk is determined by the length of time). After modification, click [Save] and directly click [Test].




Recipe interface, select the product.

After selecting the product, click [Edit] to adjust the water and powder quantities.


##### 6.4.1 New Recipe



Go to the Recipe screen, click the "Add Recipe" button, and enter the recipe name in the pop-up dialog box.




Click "Add steps", enter the corresponding parameters in the pop-up dialog box, gouache ratio.




Continue to click "Add steps", enter the corresponding parameters in the pop-up dialog box, confirm the completion of the formula, click "Save" button, select the new formula in the formula interface, and then click "test", when the drink is finished, taste it, if it is OK, otherwise you can continue to modify the goureau ratio and continue to test until you get satisfactory coffee.

#### 6.4.2 .New drink



Select the "Drink Management" button and click, and click the "Add Drink" button in the pop-up interface.




Enter the drink ID and drink name in the pop-up interface (drink ID and name can be obtained through the network management background - Reference - search, when the use of a single machine, sales data are not counted, drink ID and name can be customized).

Select the recipe in the new drink interface (select the new recipe in the previous section - Americano 1), enter the drink production time, price, sort, select the drink picture, drink status, single or double drink, confirm and click the "Save" button.



New drinks will be displayed in the beverage management interface, as shown in the figure above; Click the top left corner of the screen to return to the sales screen, which will display new drinks.


## 6.5 Drink management




Single Cup drink Interface

Double Cup drink Interface

The drink management interface can add drinks, edit all drinks, import drinks, and export drinks.



Click on the drink icon to edit the drink: drink ID (the entered ID needs to be consistent with the ID on the server), drink name, drink recipe, production time, price setting, sorting, normal display, delisting, single cup, double cup, and save function.



Click "Edit" to edit all drinks: you can select, reverse select, delete, and set prices. Selecting a drink can be checked individually. Click to set the price, enter the drink price in the pop-up dialog box, and click "OK" to confirm.

## 6.6 Drink production


- Under the user interface, select a drink;
- Adjust the taste in the touch screen, there are five levels, and then confirm; (This step can be cancelled in the factory settings according to customer needs);
- In free mode (set to 0 yuan), the machine can directly make drinks; In the payment mode, the machine will have several payment methods (such as paper currency, coins, and card payment);
- After successful payment, the machine automatically starts making drinks;
- After the drink production is completed, there will be a prompt message on the touch screen interface indicating the completion of the production;
- Customers can set the language of the user interface as needed.



1. Product List Page: Display all currently sold drinks; Language switching, sales mode, and left and right arrows are the up and down buttons.





3. Payment page: WeChat, Alipay, MDB cash, MDB swipe card. (The interface will not pop up in free mode).




4. Product Production Completion Page: The product is completed, please take it away.


## 6.7 Operator Options




Operator options has the following functions and switches: language switching, stop production, screensaver, advertising, general picture, direct making production, brewer preheating, lock screen.




Screen saver: Turn on the picture playback switch, transfer the prepared pictures to a USB drive, insert the USB drive into the USB port (located at the bottom left of the display screen), and import the pictures from the USB drive; Set the screen saver to start within the range of 0-30 minutes.




Set the screen saver interval time(5-30 seconds); Click on the carousel switch to enter the screensaver ad loop mode on/off, which allows for carousel.



Custom image: Create a "logo, start-up image" on the computer according to the requirements (size and naming of the image), then transfer them to a USB drive, and then insert the USB drive into the USB port (the USB port is at the bottom left of the display screen) to import the image from the USB drive;



First, create "background images and drink images" on the computer according to the requirements (size and naming of images), then transfer them to a USB drive. Then, insert the USB drive into the USB port (located at the bottom left of the display screen), and import the images from the USB drive;



First, create "Brewing finished image" on the computer according to the requirements (size and naming of the image), then transfer them to a USB drive, and then insert the USB drive into the USB port (USB port at the bottom left of the display screen) to import the image from the USB drive;

## 6.8 Empty

### 6.8.1 Coffee grounds bin



#### NOTE

- High temperatures may cause damage.
- Do not use the dishwasher to clean the coffee grounds bin.

First, pull out the water tray, then pull out the coffee grounds bin from the machine (refer to the following chapters for instructions).

Empty the coffee grounds bin and clean it.

Dry or wipe the powder box dry, then push the machine back into the innermost position.

The machine is ready for operation.

## 6.8.2 Water tray



### NOTE

- Pull out the water tray outward.
- Before disassembling the water tray, ensure that there is no drink output.
- When installing, ensure that the wastewater sensor is inside the wastewater tank.

## 6.9 Transportation conditions



### CAUTION

Improper transportation of the coffee machine may result in injury.

Pay attention to general health and safety instructions.

- ► please make sure to disconnect the water and power sources before changing the position.
- ► please check the ground for obstacles and unevenness before changing position.



### NOTE

- Improper transportation may cause damage to the stacker transport machine.
- When using a handcart to change the position of the machine, the following points must be noted:
- For safety reasons, when changing positions, do not push or collide with the handcart, only drag it.
- Can only tow carts, cannot tow machine.



The manufacturer shall not be liable for any damage caused by misuse of the handcart or failure to comply with the instructions for use.

The waterway should be emptied before the machine is transported. Refer to Section 7.6 for the method of emptying the waterway.



### WARNING

- Pay attention to the risk of burns when emptying the boiler!
- There is a risk of freezing during outdoor transportation, as freezing at low temperatures can easily damage the machine. The operation of emptying the boiler is required!

## 6.10 Turning off

### 6.10.1 Operation end

Standby mode



### Danger



- In standby mode, the machine is still powered on.
- Do not disassemble the chassis.
- Before carrying out maintenance work, power off the machine.

If it has not yet started, start machine cleaning in the machine background management.

Cleaning will begin

Clean daily and weekly when necessary.

Empty and clean the waste box and water tray.



Please refer to the "Cleaning" section for specific data.



After the automatic cleaning is completed, close the machine door, turn off the power switch, and unplug the power plug.

#### 6.10.2 Long downtime (over 1 week)



In case of prolonged downtime such as company holidays, the coffee machine and other ancillary equipment must be turned off.

- Empty the water tank or close the inlet valve.
- Unplug the power plug or turn off the main switch installed at the device to power off the machine.

If the ambient temperature of the coffee machine is below zero degrees, the boiler must be emptied beforehand;

- Execute the "Maintenance" section in the "Machine Set-up" section; Pre-freeze protection for boiler transportation.
- Please contact the machine manufacturer or operating agent.



#### NOTE

- Frozen and swollen water may damage pipelines and water boilers.
- If the temperature in the room is likely to drop below freezing point, the water boiler must be emptied.



Before running and debugging again for the first time, a daily cleaning must be carried out.

## 7 Cleaning

Thorough cleaning and maintenance are the basic requirements for achieving food hygiene conditions. Only through regular maintenance (twice a week or increasing cleaning frequency based on specific usage), cleaning, and upkeep can the machine provide superior taste drinks and satisfy customers.

### 7.1 Cleaning interval

Cleaning interval				
Daily	Weekly	Actual	Actual	
Automatic cleaning				
X				Hot water rinsing (system rinsing)
X				Regular cleaning (set time for cleaning)
Cleaning procedures				
X			X	Waterway system rinsing
X			X	Coffee system rinsing
X			X	Milk system rinsing
X			X	Mixer rinsing
Manual cleaning				
X				Cleaning waste bin
X				Clean the water tray
X				Clean the cup holder
X				Clean the mixer module
X				Clean the touch screen
X				Clean the drink spout
X				Cleaning milk container
	X			Cleaning coffee bean container
	X			Cleaning waste bins
	X			Clean the exterior of the coffee machine and refrigerator
		X		Clean the small water tank
		X		Clean Brewer
Illustration				
Daily	Execute at least once a day and increase the frequency if necessary.			

Weekly	At least once a week, increase the frequency if necessary.
Actual	According to demand (when contamination occurs).
Actual	According to demand (when contamination occurs).

## 7.2 Cleaning plan

The following two cleaning plans are available for technical service personnel to configure:

The cleaning plan of "Jetinno Intelligent Derror" (standard).

A "manual" cleaning plan.



### NOTE

The cleaning intervals described in this chapter comply with the cleaning plan of "Jetinno Intelligent Derror". These settings comply with the Hygiene Management Standards for Ready made and Sold Autovending Machines. When the cleaning level is set to "none", the operator is responsible for carrying out necessary cleaning work.



Refer to the "JL series coffee machine cleaning and maintenance manual" - "Hygiene management standards for on-site vending machines".





The screen displays pending or executed cleaning messages, depending on the selected configuration in the cleaning plan.

## 7.3 Daily rinsing

### 7.3.1 Brewer rinsing




At the top of the screen, click the rinse button on the brewer and select the "OK" button in the pop-up dialog box.




The interface for rinsing the brewer pops up, and the machine executes the rinsing program. After the program ends, it automatically returns to the ordering interface, displaying "Operation successful".

### 7.3.2 Milk system rinsing




At the top of the screen, click the Milk system rinsing button and select the "OK" button in the pop-up dialog box.




The rinsing milk system interface pops up, and the machine executes the rinsing program. After the program ends, it automatically returns to the ordering interface, displaying "Operation successful".

### 7.3.3 Mixer rinsing





Enter the machine background, click "Cleaning and Maintenance", select "Powder", and click the button; Click "OK" in the pop-up dialog box until the cleaning program ends





Click "OK" in the pop-up dialog box until the cleaning program ends.



### 7.3.4 Automatic rinsing settings





Timed rinsing: Enter the machine background, Cleaning/Care, set cleaning settings, and set automatic cleaning time from Monday to Sunday at a certain time every day.





Interval Rinsing Brewer: Go to "Product Set-up", select Coffee ->Auto-rinse time, and you can set the brewing machine's rinsing interval time and rinsing water volume.



Auto-rinse interval time[min]: Go to "Product Set-up", select "Fresh Milk ->Auto-rinse time", and you can set the interval time for milk system rinsing.



Interval rinsing mixer: Enter "Product Set-up" and select "Left Powder and Right Powder" respectively;



Select "Auto-rinse interval time[min]" to set the interval time and rinsing water volume of the mixer.

### 7.3.5 Cleaning of water tray



**CAUTION**



Sediments and bacteria can contaminate the water tray.

Rinse and clean the water tray daily.

Please wear gloves when cleaning.



- Cleaning method for water tray: Pull the water tray out of the machine.
- Thoroughly brush the water collection tray with clean water, household cleaning agents, and a brush.
- Rinse with water and dry with a clean towel.
- Reinstall the dried water tray into the machine and check to ensure it is pushed to the bottom.

### 7.3.6 Cleaning of waste bin



#### CAUTION

- The coffee grounds in the waste bin are prone to mold formation. If the plaque spreads to the machine, coffee may be contaminated.
- Therefore, it is necessary to clean the waste bin every day.
- 



#### NOTE

- High temperatures may cause damage.
- Do not use dishwasher to clean waste bins



Cleaning method for waste bin:

First, remove the water tray from the machine; then take out the waste box from the machine and pour out the coffee grounds.

Thoroughly clean the waste bin with clean water and household cleaning agents.


Rinse with water and dry with a clean towel or air dry.

Reinstall the waste bin into the machine.

### 7.3.7 Clean and disassemble the foamer

1, In order to ensure the normal operation of the milk foam, and for health considerations, if you have made milk before, please be sure to perform milk system deep cleaning (cleaning with liquid medicine) on the **same day**, the operation method is referred to 7.4.4 milk System Cleaning.

2、Manually disassemble and clean the milk foamer, the specific methods are as follows:



As shown in the picture above: pull out the nipple of the milk tube backward and pull out the milk tube;



As shown in the picture above: hold down the buckle on both sides of the drinkoutlet mouth, pull down hard, remove the discharge mouth, and disassemble the milk foamer into a single component;



Every day, the steam nozzle, milk tube, milk tube connector, duck-bill check valve, fresh milk heating chamber, rubber sleeve and mouth out of the mouth. Soak the removed parts in 500ml (water + milk cleaner 1 tablet) milk cleaning solution overnight, and then thoroughly rinsing under running water; In the rinsing process, if the milk dirt is found to be serious, after soaking, you should use a small inner hole cleaning brush to insert the air inlet hole and milk inlet hole to wash the two channels.

Before cleaning the milk inlet hole with a cleaning brush, remember the current position of the screw, then turn counterclockwise 4 times, clean the milk inlet hole with a small brush, rinsing and turn the temperature adjustment screw back to the original position.

The installation method of other components is opposite to the disassembly method.

Note: If it is found that there is no milk (milk system is blocked) or only milk is not frosted (air path is blocked, priority is to clean the duck bill check valve, air intake and steam intake - the vertical channel).

The duckbill check valve is small, and be careful to be washed away or lost when rinsing with water.

## 7.4 Regular cleaning

### 7.4.1 Cleaning agents



#### CAUTION

- Cleaning agents can cause poisoning!
- Only cleaning agents recommended by the equipment manufacturer are allowed to be used.
- Cleaners should be kept away from children.
- Do not consume or directly touch the cleaning agent with your hands.



Before using cleaning agents, it is necessary to carefully read the instructions and safety data sheet on the packaging. If no safety data sheet is provided, please request it from the dealer.



#### NOTE



- Using the wrong cleaning agent may damage the machine!
- Use only the manufacturer's recommended cleaning agents for daily and weekly cleaning.

## Brewer Cleaning tablets

Information		
	Usage	Cleaning of coffee machine system
	Cleaning purpose	Remove oil residues from the coffee system
	Interval	Daily

## Milk system cleaning tablets:



- Tablets can dissolve quickly in warm or cold water.
- Containing cationic surfactants to improve cleaning safety and strength.
- Safe, easy to clean, improve transportation efficiency, and reduce transportation costs.
- Ratio: Mix 1 tablet with 250 milliliters of water.
- Product specifications: 4g/tablet, 120 pieces/bottle, 12 bottles/box.



### CAUTION

- There is a risk of burns. When washing the machine, the drink outlet outputs hot water.
- Do not reach your hands below the drink outlet during machine rinsing.

## 7.4.2 Display screen guided cleaning program

Preparation - necessary tools for cleaning.

Coffee system cleaning tablet [1 tablet].

Household washing aid.

Clean kitchen cleaning towels [2 pieces]

Collect containers

Start cleaning program



### CAUTION



- Cleaning agents can cause poisoning.
- When cleaned machine components are contaminated with cleaning agents, it can cause harm to the body
- Harm to physical health.
- Please wear gloves during the cleaning procedure.



### CAUTION

- During the operation of the cleaning program, high-temperature liquid will be output. During cleaning, do not extend your hands to the outlet position
- Below, otherwise there is a risk of burns.



## NOTE



- Obstruction of wastewater drainage will cause the drip tray to overflow.
- Check the wastewater discharge outlet of the drip tray before starting the cleaning program.





The cleaning process can be interrupted at any time. After the cleaning is interrupted, the coffee machine is not in a state of operational readiness. The cleaning program forcibly shuts down. Restart the interrupted cleaning program as soon as possible.

Start the cleaning program in the maintenance menu. The touch screen will guide the user through all the necessary operations.


### 7.4.3 System cleaning




Enter the background of the machine - click Cleaning/Care, select System Cleaning, and click the System Cleaning button;




Click "OK" in the pop-up dialog box to enter the next interface, according to the interface prompt: empty the water tray, waste residue box, water tank, and then click "Next".



Please operate according to the display interface: take out the milk hose and insert the cleaning container with 500ml water and 30ml milk cleaning solution. Put the empty container of 2L under the outlet (the one with the drainage function outside the water tray can not put the 2L container). Click "Next" and follow the prompts: open the door and place the cleaning tablets into the brewing chamber, then close the door.



The machine is performing cleaning, cleaning... Please wait, when the progress is completed, the next interface will pop up, follow the prompts: take out and clean the milk tube, empty and clean the container, pour 500ml of water, insert the milk tube, click "Next" to continue.





The machine is performing cleaning, cleaning..... Please wait, when the progress is completed, the next interface will pop up, follow the prompts: Please clean the blender, please clean the milk tube and put back in the milk tank. Disassemble the drink mouth and blender regularly for cleaning, and click "OK".

#### 7.4.4 Milk system cleaning

Daily cleaning, put the fresh milk system cleaning agent into the cleaning box, the recommended cleaning frequency is once per day. According to the amount of cleaning agent and water, the proportion of the corresponding solution, the milk tube into the cleaning box.





Enter the background of the machine - click "Cleaning/Care" - "Fresh milk cleaning"; In the pop-up dialog box, select [OK] to go to the next step, select [Cancel] to return to the menu of the previous layer; Click [OK] to go to the next step.



Please operate according to the display interface: Take out the milk tube and insert the cleaning container with 500ml water and 30ml milk cleaning solution. Put the empty container of 2L under the outlet (the one with the drainage function outside the water tray can not put the 2L container). Click "Next", the machine is performing cleaning. Milk path cleaning, please wait...

When the progress is complete, the next interface will pop up.




Follow the prompts: remove and clean the milk tube, empty and clean the container, pour 500ml of clean water, insert the milk tube and click "Next" to continue. When the progress is complete, the next interface will pop .




Follow the prompts: Please return the milk tube to the milk crate. Click "Next" to proceed. When the next interface pops up, the screen will prompt: Milk road cleaning is finished, click "OK" to finish.


#### 7.4.5 Brewer Cleaning




Enter the background of the machine and select "Cleaning/Care -> Brewer Cleaning". Click "OK" in the dialog box that pops up. Go to the next interface.



Please operate according to the screen prompt: whether the water tray is empty and installed back (the water tray with drainage function outside the belt can be ignored). Click "Next" to continue. Follow the prompts in the next interface: Please fill the tank to the maximum water level (4L). Place a 2L container at the outlet port (the one with the drainage function outside the water tray can be ignored). Click "Next" to continue.




Follow the prompts: Open the door and place the cleaning tablets into the brewing chamber, then close the door. Confirm that the cleaning tablets have been put in? Click "Continue Next".




Cleaning, please wait... When the progress is complete, the next interface will pop up and the Brewer Cleaning is complete, click "OK" to return to the order interface.

#### 7.4.6 Deep cleaning mixer

Recommended cleaning time: the top cover of the agitator is cleaned 2-3 times a week, the upper and lower cover of the agitator body and the steam inlet of the agitator is cleaned once a week, and the V-shaped sealing ring, gland and impeller are inspected once every 3 months for damage.



Open the machine door; Draw the upper cover of the lower agitator upward; Turn the handle on the fixed seat clockwise to unlock the lock; Pull out the agitator body, and be careful that the O sealing ring on the outlet mouth is removed when taking the agitator body (arrow in the figure below); Draw the steam cover outward; Pull out the mixing impeller with both index fingers; Take out the V-seal ring;



Pull out after turning the gland clockwise; Wipe the mixer holder with a towel or 75% alcohol wipes; Clean the mixer body, gland, V, O seal ring, mixing seal, mixer steam inlet upper and lower cover; V, O seal ring check regularly whether damaged, damaged to replace in time. The mixer is restored after cleaning, and the installation method is contrary to the disassembly, no longer described.

#### 7.4.7 Cleaning touch screen

Wipe the touch screen with a clean towel



- Unintentionally exporting a drink while cleaning can cause burns.
- Turn off the machine before cleaning by locking the screen or cleaning the operating panel.



## NOTE

- Damage to the touch screen during cleaning.
- The stain cannot be removed by grinding. Do not press the display with brute force, high pressure, or sharp objects.

### 7.5 Clean the coffee bean container weekly



## CAUTION



- The rotary grinding blade of the grinder and the coffee bean slot opener blade are sharp and pose a risk of injury.
- Do not put your hand into the coffee bean slot while the coffee machine is on. Wear gloves when cleaning.





## NOTE



- Coffee bean grooves scratched.
- Do not use the abrasive type of stain remover.

### 7.6 Empty waterway

Waterways must be emptied when long distances transportation below zero degrees Celsius, as follows:




Press the top left corner of the screen for a while, enter the password test9527 in the dialog box that pops up, go to the background of the machine, and click "Machine Set-up".




Select the "Maintenance" button, click the "Boiler transport antifreeze protection" button in the pop-up interface, and operate according to the interface prompt: place a water receiving container under the water outlet. Click

"YES" to begin emptying the boiler.


## 7.7 Descaling





Enter the background of the machine, click the "Cleaning/Care" button, and select "Descaling" in the dialog box that pops up.





The descaling time is about 60 minutes. Press "OK" to start descaling and click "No" to cancel descaling. Click "OK" to enter the next interface, and follow the prompts to "empty the drip tray and put it back"; Follow the prompts and click "Next" to go to the next interface.




Follow the screen prompts to operate: Fill the tank to the maximum water level (4L) and then put it back. Click "Next" to continue; Follow the prompts in the pop-up interface: Place an empty 2L container under the outlet. Click "Next" to continue.



Screen notice: pay attention to hot water and steam splashing from the outlet. Click on "Next"; The interface that pops up shows: "Water system is cooling, please wait" (issue an instruction to lower boiler temperature to 60 degrees), and a progress bar appears at the bottom of the screen. When the progress is complete, the next interface pops up.




Follow the on-screen prompts: "Please remove the tank and empty it, remove the water filter; Pour 2 bottles (750ml each) of WMF descaling solution and 750ml of clean water into the tank and fill\* it back "and click" Next "to go to the next interface.



The interface prompts "Confirm whether the descaling solution has been added and the tank has been replaced". After confirmation, click "Next" to go to the next interface;


The screen prompts "Place a 2L empty container under the outlet", after confirming, click "Next" to enter the next interface.




The screen shows "The machine is descaling, please wait..." ", the progress bar appears at the bottom of the screen, when the progress is completed, it automatically jumps to the next interface, the screen displays "take out and empty the tank, rinse the tank with water", operate according to the screen prompt, take out the tank and empty it, rinse the tank with water, click "Next" to go to the next interface.





Follow the prompt on the screen: "Fill the water tank to the maximum water level (4L), then put it back", click "Next", go to the next interface. The screen prompts "Place a 2L empty container under the outlet", operate according to the prompt, confirm and click "Next" to go to the next interface.





The screen shows "Descaling, please wait a moment..." , a progress bar appears at the bottom of the screen. When the progress is complete, go to the next interface.





Follow the prompt on the screen: "Fill the tank to the maximum water level (4L) and put it back" and click "Next" to go to the next interface. The screen prompts "Place a 2L empty container under the outlet", operate according to the prompt, confirm and click "Next" to go to the next interface.




The screen displays "Descaling, please wait a moment..." (The two boilers are heated to 94 degrees, opening the separate hot water valve and the holding valve during the heating process), and a progress bar appears at the bottom of the screen. When the progress is complete, go to the next interface.



Follow the prompt on the screen: "Fill the tank to the maximum water level (4L) and put it back" and click "Next" to go to the next interface. The screen prompts "Place a 2L empty container under the outlet", operate according to the prompt, confirm and click "Next" to go to the next interface.



The screen displays "Descaling..., please wait" (Perform 1 rinse of the whole machine, about 0.75L water; Heat two boilers to standby temperature; 3S steam from the steam nozzle), a progress bar appears at the bottom of the screen;



When the progress is completed, the screen jumps to the completion interface, the screen displays "descaling successfully", click to confirm completion, go to the standby state.

#### Special note

- (1) There is no cancel button in the middle of descaling, and it must be completed in accordance with the process.
- (2) If the descaling is stopped in the middle due to human or other reasons such as power failure, the next restart will prompt you to finish descaling or restart descaling, otherwise the machine cannot be locked to make any drink; Because the boiler is full of agents during descaling, drinks can not be made.

## 8 List of Common Problems

Problems(Questions)	Possible causes	Solution
Coffee flow rate is too slow	The coffee is ground too fine	Adjust the grinder and rotate to the side with the larger number
	The dose is much larger than expected	Recalibrate the grinder
	Strainer blocking	Pills to clean the brewer or replace the strainer
	Leaks (lower plunger damaged)	Replace the plunger or brewer
	Brewer O-ring leak	Replace the seal ring
Contaminated water tray	No cleaning for a long time	Clean the water tray
	The outlet spout is not installed correctly	Check and reinstall
Coffee flows too fast	The coffee is ground too coarse	Adjusting grinder
	The dose is not nearly as good as expected	Recalibrate or check the recipe Settings
The waste bin is full	The cumulative count of coffee ground cakes since the last empty has reached 40	Pull out the water tray, remove the coffee grounds box, and empty the grounds box
Boiler filling fails	Prolonged machine shutdown and deactivation (water valve not open)	Turn on the water valve to restart the machine
	The first time the machine is used, there is air in the waterway system	Power off and try again to vent
Lack of coffee beans	The coffee beans in the container have been used up	Add the appropriate amount of coffee beans to the coffee bean container
	Too much fat sticks to the coffee beans	Stir the coffee beans in the container
The water tray is not installed	The water tray is not installed properly	Reinstall the water tray
	The water tray sensor is damaged \ magnet is missing or damaged	Replace the sensor \ magnet
Water tray full	The water tray is full	Pull out the water tray and empty the waste water
	The water level monitoring metal plate of the water tray is dirty	Clean and dry the monitoring metal strip
Unable to suck milk	Milk crate is empty	Check that the milk carton is filled with milk

	Clogged steam line or steam outlet	Use potions for deep cleaning of the milk system
	Broken steam line	Disassemble steam line or outlet, check and replace
	The temperature adjustment knob of the milk frother is too tight	Loosen the temperature adjustment knob of the milk dispenser to the proper position
	The frother is blocked	Remove the milk frother to check all holes and clean; Replace the foam with a new one
The coffee maker needs descaling	The cumulative production of the coffee machine reaches the set amount of water or cup, indicating the need for descaling; The threshold value of the prompt can be modified in the background menu of the machine.	Click the prompt button to remove the scale, the specific operation method refer to the manual

## 9 Preventive measure

### 9.1 Cleanser

#### 9.1.1 Use



#### CAUTION

Danger of poisoning from ingesting detergent.

- Be sure to observe the following:
- Cleaning agent storage should be kept away from children and unauthorized persons.
- Do not ingest cleaning agents.
- Do not mix cleaning agents with other chemicals or acids.
- Do not add cleaning agent to the cup.
- Do not add cleaning agent to drinking tank (inside/outside).
- Cleaning agents and descaling agents should only be used for their stated purpose (see label).
- Do not eat or drink while using the cleaning agent.
- Good ventilation and venting must be ensured when using the cleaning agent.
- Protective gloves should be worn when using the cleaning agent.
- Safety goggles should be worn when using detergent.
- Wash your hands thoroughly immediately after applying the detergent.



Read the package instructions carefully before using the cleaner. If a safety data sheet is not provided, you can ask the distributor for it (see Packaging of the cleaner)

### 9.1.2 Storage

Be sure to observe the following:

- Keep out of reach of children and unauthorized persons.
- Keep away from heat, light and moisture.
- Store separately from acidic substances.
- Store in original packaging only.
- Store the cleaner separately.
- Do not store with food or drinks.
- Comply with local laws regarding the storage of chemicals (detergents).

### 9.1.3 Disposal of waste

If recycling is not possible, the cleaner and its storage must be disposed of in accordance with local laws.

## 9.2 Health Regulations

### 9.2.1 Water



#### CAUTION

The possible health hazards of not using water properly!

The water source should meet the GB5479 sanitary standard for drinking water.

Be sure to comply with the following points:

The water must be clean and pollution-free.

- Do not add seepage water or other corrosive water to the coffee maker.
- The carbonate hardness should not exceed 5-6 °DKH (German carbonate hardness) or 8.9-10.7°FKH (French carbonate hardness).
- The total hardness value must always be higher than the carbonate hardness.
- The minimum carbonate hardness is 5 °DKH or 8.9 °FKH.
- The maximum chlorine content is 50 mg per litre.
- PH 6.5-7 (pH neutral).
- Equipped with filters (internal & external)

### 9.2.2 Coffee



#### CAUTION

Not using coffee properly could be taking a toll on your health!

Be sure to follow the following:

- Check the bag for damage before filling.
- Close the coffee bean tank top immediately after adding coffee beans.
- Coffee should be stored in a dry, cool and dark place.
- Coffee should be stored separately from cleansers.
- The earliest purchased product should be used first (" early in, early out ").
- The package should be sealed properly after opening to keep the product in the package fresh and prevent it from becoming contaminated.

### 9.2.3 Finished drink powder



#### ⚠ CAUTION

The wrong use of drink powder can cause damage to your health!

Be sure to follow the following:

- Inspect the package for damage before opening it.
- Store finished drink powder in a dry, cool place.
- The finished drink powder must be stored separately from the cleaning agent.
- The earliest purchased product should be used first (" early in, early out ").
- Please use it within the shelf life.
- The package should be sealed properly after opening to keep the product in the package fresh and prevent its contamination.

## 10 Safety and Quality Assurance

The manufacturer does not accept any responsibility for damage that may occur to the coffee machine if the user does not follow the instructions for the use and installation of the machine.

Take care to follow the instructions.

The installation site should be kept dry and waterproof; It is strictly forbidden to use the machine in the open air; The machine can only be used for the specified raw material package; Other raw materials are regarded as abnormal use, resulting in damage, the manufacturer does not assume any responsibility.

Whether the Buyer is entitled to warranty rights, and what specific warranty rights the buyer may be entitled to, depends on the agreement between the buyer and the seller. Failure to comply with the operating instructions forfeits warranty rights.

The warranty will not be fulfilled if:

1. Natural wear and tear that occurs in all parts.
2. Machine defects caused by non-compliance with the operation, cleaning and maintenance regulations of the machine (such as operating instructions and cleaning and maintenance).
3. Defects caused by not using the original parts of the manufacturer or by a third party's wrong installation or careless use of the machine.
4. Machine defects caused by improper modification or repair of the machine by the user or a third party without our permission.
5. Machine defects due to improper or incorrect use.